

Your Pipeline To Quality Valves, Strainers, Flowmeters and Controls

55 Guardsman Road Thornhill, Ontario L3T 6L2 Canada

Tel: 905-889-7890 Fax: 905-889-8553

MAINTENANCE INSTRUCTIONS For Chemline Multi-L Port True Union Ball Valve Sizes 1/2" to 4"

Maintenance:

Refer to **ASSEMBLY DRAWING TUMP rev 0.** And proceed as follows:

- 1. Loosen union nuts (5) and remove valve from line. (Note: make sure there is no pressure in the line before removing valve).
- 2. Set valve to the closed position.
- 3. Loosen and remove setscrew (13).
- 4. Remove handle (7) and end connectors (4).
- 5. Unscrew both carriers from the body (1).
- 6. Gently push ball (2) out of the body (1).
- 7. Remove stem (8) by pushing it into the body (1).
- 8. Remove and inspect o-rings (9, 10 & 11).
- 9. Remove and inspect ball seats (6) and seat cushions (12).
- 10. Lubricate stem o-rings with Dow Corning III silicone compound or equivalent.
- 11. Replace any worn or abraded parts.
- 12. To reassemble valve, reverse steps 1 through 11.

09/19/01 Page ½

